



EMA Manager User Manual

Android Version 1.0.4

APsystems Jiaxing China

No. 1, Yatai Road, Nanhu District, Jiaxing, Zhejiang

Tel: +86-573-8398-6967

Mail: info@APsystems.cn

Web: www.china.APsystems.com

APsystems Shanghai China

Rm.B403 No.188, Zhangyang Road, Pudong, Shanghai 200120,P.R.C

Tel: 021-3392-8205

Mail: info.global@APsystems.com

Web: global.APsystems.com

© All Rights Reserved

Table of Contents

INTRODUCTION	1
1. INSTALL AND LOGIN EMA MANAGER	2
1.1. INSTALL	2
1.2. LOGIN	3
2. HOME (INSTALLER LEVEL).....	4
3. USER (INSTALLER LEVEL)	8
3.1 HOME (END USER LEVEL)	11
3.2 MODULE (END USER LEVEL)	12
3.3 DATA (END USER LEVEL).....	13
3.4 WORKSPACE (END USER LEVEL)	14
4. WORKSPACE (INSTALLER LEVEL)	16
4.1 USER MANAGEMENT (INSTALLER LEVEL).....	17
4.1.1 Adding a New User Installation.....	17
4.1.2 Adding a New Share User Installation.....	40
4.1.3 Resume an Incomplete Registration	44
4.2 INSTALLER MANAGEMENT (INSTALLER LEVEL)	46
4.2.1 Adding a New Module	46
4.3 REMOTE CONTROL– ECU MANAGEMENT (INSTALLER LEVEL)	48
4.3.1 Manage Inverter UIDs	51
4.4 COMPANY MANAGEMENT (INSTALLER LEVEL)	53
4.4.1 Adding a New Staff Account (Installer Level).....	53
4.4.2 Adding a New Department (Installer Level).....	56
5. LOCAL CONTROL (ECU APP).....	58
5.1 HOME (ECU APP).....	60
5.2 MODULE (ECU APP)	61
5.3 DATA (ECU APP)	62
5.4 WORKSPACE (ECU APP).....	64
5.4.1 ID Management	65
5.4.2 Grid Profile	67
5.4.3 Inverter Connection Progress	68
5.4.4 ECU Network Settings	69
5.4.5 ECU AP Settings.....	71
5.4.6 ECU Data Settings.....	72
5.4.7 Meter Settings.....	73
5.4.8 Automatic System Check.....	77
6. DO-IT-YOURSELF REGISTRATION (ECU APP).....	78
7. MANAGE YOUR INFORMATION (INSTALLER LEVEL)	80

7.1	MODIFY ACCOUNT INFORMATION (INSTALLER LEVEL)	81
7.2	RESET PASSWORD (INSTALLER LEVEL)	82
7.3	MODIFY COMPANY INFORMATION (INSTALLER LEVEL).....	83
7.4	CHANGE APP'S LANGUAGE (INSTALLER LEVEL)	84

Introduction

EMA Manager is a one-stop application specially made for APsystems registered professional solar installers. The content of the EMA Manager is the APP version of features available in installer account via the web portal.

The EMA Manager APP will allow installers, to register end-users, new PV systems, to monitor performance and ensure easy access to all key data without having to log into their laptop.

1. Install and Login EMA Manager

1.1. Install

iOS:

- Go to App Store
- Search “EMA Manager”
- Download and install



Note

iOS: 10.0 and up

Android:

Method 1

- Go to Google Play Store
- Search “EMA Manager”
- Download and install

Method 2

- Open <https://apsystems.com>
- Select your region
- Click the tab menu “Apps” below “Products”
- Download and install

Method3

- Open <https://www.apssystemsema.com>
- Scan the QR code for Android or IOS
- Download and install



Note

Android: 7.0 and up

1. Install and Login EMA Manager

1.2. Login


- Enter your “Username” and “Password”.

Note

Use installer account Username and Password. The Password is case sensitive.

- Press the “Login” button.


On the home page, a dashboard of your installed portfolio is displayed



Note

- If no installation is registered, the dashboard will be empty.
- if you need to switch the language, click the “English” at the upper right corner and select language of your choice.

2.Home (*Installer Level*)



On the home page, installer can visualize

- User: Total number of installations
- Device: Total number and type of micros or ECUs installed
- Energy: cumulative energy produced by the installed portfolio

On the home page, data are shown per year, but you have also access to prior day performance (yesterday)





Note

Installers with a network of sub-installers can also access to the details of their sub-installers. But they are not permitted to view the operations and productions directly belonging to their sub-installers for the data security and privacy.


By pressing “more” for each category, there is more granular data available:

- Per quarter
- Per system size

2.Home (Installer Level)




2.Home (Installer Level)



The “more” information shown above are also available via menu below “Report” in **[Workspace]**.

- Operation: View more granular data of user and device.
- Production: View more granular data of production.

2.Home (*Installer Level*)




3. User (Installer Level)

You can view the detailed production of a single user the same as it shown in EMA APP to the users.

1. Once logged-in, Select the tab menu [**User**] at the bottom of the page.

A list of users is displayed.



Note

A list of your sub-installers can also be displayed if you are a Master installer.

2. Select the user.
There are multiple selections for you to quickly search.


➤ User List

Click the icon at the right side of the search field, the multiple choice of selections is displayed.

3. User (*Installer Level*)


Display

You can select the fields you want to display in the user list.



Filter

You can also filter the user system with system running status and system type.



3. User (Installer Level)

Green: The system is functioning normally

Yellow: Some micro-inverters communications has been interrupted since beginning of day or the micros have not been properly registered (wrong UID, typo in the UID)

Red: ECU has been disconnected from the internet (power outage, change of router, change of wifi password, wear and tear of the Ethernet cable, loose wifi antenna)


Grey: The system has never reported data (ECU might be connected to the internet, but the micros have not been synchronized in the ECU during commissioning)

Share ECU User: Multiple customers' PV system can be monitored via a single ECU using ECU Share mode. We call these user "Share ECU User".

ECU-C (Meter Activated): The system is using an ECU-C, with metering functions activated and CTs (current transformers) in place.

Sort

You can select one field to sort the list.



Reset


Click it to reset the query conditions into default settings.



3. User (*Installer Level*)

3.1 Home (*End User Level*)


In this view, you can view the registrations and productions of the user's system with the running status.



3. User (*Installer Level*)

3.2 Module (*End User Level*)

In this view, you can view each panel's power in the whole day or daily energy in 30 days. By using the sliding bar, the data will be automatically shown as per time of day




3. User (Installer Level)

3.3 Data (End User Level)

In this page, you can view the detailed data on ECU level and inverter level:

- Per day
- Per month
- Per year



Note

If the system is using an ECU-C, with metering functions activated and CTs (current transformers) in place, you can also visualize PV production, house-hold consumption and grid import/export data on meter level.

3. User (*Installer Level*)


3.4 Workspace (*End User Level*)

In this view, the name of the end-user is visible on the top left hand-side of the header.

In this View, you can manage the chosen user's registration information, change the user's security information, replace the devices and configure the system remotely.

Note

This is specific to one single end user.



3. User (*Installer Level*)

➤ **Account Details**

- **Personal information:** Edit the end user's personal information.
- **ECU:** Add/Edit/Delete ECUs.
- **Inverter:** Add/Edit/Delete inverters.
- **Group View:** Add/Edit/Delete group views.
- **Upload picture:** Upload/Delete pictures.

➤ **Account Security**

- **Reset password:** Send the reset password email to the end-user.
The end-user will receive a link at his registered email address. By pressing this link, he will be able to reset his password.
- **Reset username:** Apply a new username.
The end-user will be informed of the new username by an email after the new username is agreed.

➤ **Replace Device**

- **ECU-replace:** Replace the ECU device.
- **Inverter-replace:** Replace the inverter device.

➤ **Remote Control**

- **ECU-remote:** Manage Inverter UIDs in ECU, Set Grid Profile to ECU
Works only if the ECU is connected to the internet.



Note

Click "*Delete*" at the upper right corner of the page to delete this user.


4. Workspace (Installer Level)

In this View, you can manage the user's registration information and installer's registration information, configure the system remotely and get granular data of multiple reports.

This is a specific to all end users.

1. Once logged-in, Select the tab menu [**Workspace**] at the bottom of the page.

A list of functions is displayed.



➤ User Management

- **Add User:** Add a new user installation.
- **Add Share User:** Add a new share ECU user installation.
- **Incomplete User:** Resume the registration in case you were interrupted in any of the registration steps.

4. Workspace (*Installer Level*)

➤ **Installer Management**

- **Module:** Manage your module template or for your sub-installers.

➤ **Remote Control**

- **ECU-remote:** Manage Inverter UIDs in ECU, Set Grid Profile to ECU
Works only if the ECU is connected to the internet.

➤ **Report**

- **Operation:** View the statistics data of user and device.
- **Production:** View the statistics data of production.



Note

You can enter “*Local Control (ECU APP)*” without logout, switch your smart phone or tablet to connect to ECU local Wi-Fi and click the “*ECU APP*” at the upper right corner. **For more details, view “5. Local Control (ECU APP)”.**

4.1 User Management (*Installer Level*)

Introduction of the two different users.

User: Single end-user with one or multiple ECUs

Share User: Share-user is specific to the use of an ECU-Share: 1 ECU to monitor several installations with a generic view for the installer and separated view for each user (typical use case: Social Housing)

4.1.1 Adding a New User Installation

There are five (5) major steps involved in adding a new installation (registering) in the EMA Manager. All the following introductions take the customer as an example.

Step 1: Personal Information-Entering the customer’s personal information.


Step 2: ECU Information - Configuring the Energy Communication Unit (ECU).

Step 3: Inverter Information - Configuring the Inverter Information.

Step 4: Group View Information - Configuring the Group View.

Step 5: Upload Pictures (optional) - System Picture and/or Drawing Picture

4. Workspace (*Installer Level*)



1. Select the ***“Add User”*** icon.

Start to add a new end user account.

Step 1: Entering the Customer’s Personal Information

2. Click ***“Add Personal Information”***.

4. Workspace (Installer Level)

The screenshot shows a mobile application interface for adding a new user. The title bar is orange with a back arrow, the time 20:04, and the text 'Add User'. The status bar at the top shows various icons and a 100% battery level. The form is divided into several sections, each with a header and a plus icon to add more items:

- Personal Information**: Header with a person icon. Below it is a plus icon and the text 'Personal Information'.
- ECU Information**: Header with a car icon. Below it is a plus icon and the text 'ECU'.
- Inverter Information**: Header with a battery icon. Below it is a plus icon and the text 'Inverter'.
- Group View Information**: Header with a group icon. Below it is a plus icon and the text 'Group View'.
- Upload Picture(Optional)**: Header with a camera icon. Below it is a plus icon and the text 'Picture'.

The New User page is displayed. It divides personal information into “Account Info” and “System Info”. Fill in the customer details by field; make sure including all required information.

4. Workspace (Installer Level)

14:47 Account Info

Personal Information ^

Collect the account and system information. Account Info: username, password, personal information and contact information. System Info: the address of PV system, the basic configuration of PV system.

Account Info

Username *
1-60 bit letters,digits,underscores,@,spaces or.
please enter

Password *
Length 6-32 bits, must contain numbers and letters
please enter

Firstname *
please enter

Lastname - Optional
please enter

Email *
please enter

Phone - Optional
please enter

Allow visitors to access to this system ☐
Enabled this function, users can display this system on other websites through embedded services. Refer to [help] for operation details.

System Info

Installer *
APSInstallertest

14:48 Account Info

Country *
China

State/Province *
Zhejiang

City *
please enter

Address - Optional
please enter

Postal Code - Optional
please enter

System Size (kW) *
System Size(kW) = Pmax(W) * Number of Modules / 1000
please enter

Module Type *
please enter

Module Maximum Power(Pmax) (W) *
200-1000
330

Grid Type *
120V 120V Single-phase

Remark
please enter

0/200

OK

➤ Account Info

Username

This is a single “name” (typically the customer’s last name) that identifies this specific customer’s installation. The username appears in the customer’s area on the EMA. **(Required)** Only “letters”, “numeric digits”, “underscores”, “@”, “spaces”, and “.” Can be used when creating a username. And the username is not case sensitive.



Note

A username cannot be modified, once you submit the *PERSONAL INFO*. If your customer wants to modify the username, you can submit the username modification application after finish account registration. For details, please refer to “4.4 Workspace (End User Level)”.

4. Workspace (*Installer Level*)

<i>Password</i>	This is a temporary password that is emailed to your customer so they can access their account on the EMA. Your customer can change their password should they so choose. (Required) The set password must contain letters and numbers.
<i>First Name</i>	Your customer's first name. (Required)
<i>Last Name</i>	Your customer's last name. (Optional)
<i>Email</i>	This is your customer's email address. (Required)
<i>Phone Number</i>	Your customer's phone number. (Optional)
<i>Allow visitors to Access to this system</i>	Your customer can share his system on other website. (Optional)



Note

If enabled, it will display an authorization code to be used in embedding this specific customer's system on other website.

➤ System Info

<i>Installer</i>	This field is automatically generated by the system and can be changed using the pull-down selector if necessary. (Required)
<i>Country</i>	This field is automatically generated by the system and can be changed using the pull-down selector if necessary. (Required)
<i>State/Province</i>	This field is automatically generated by the system and can be changed using the pull-down selector if necessary. (Required)
<i>City</i>	Customer's city. (Required)
<i>Address</i>	Customer's street address. (Optional)
<i>Postal Code</i>	Customer's postal code. (Optional)

4. Workspace (*Installer Level*)

<i>System Size</i>	Customer's overall system size. (Required)
<i>Module Type</i>	Customer's solar panel type. (Required)
<i>Module Maximum Power(Pmax)</i>	The maximum power of customer's solar panel. (Required)
<i>Grid Type</i>	Grid environment where the system is connected to the grid (Required)
<i>Remarks</i>	Add any notes that you may find useful at a later date. (Optional)

3. Click "OK".



Note

Once you have clicked "OK" button in any of the major registration steps (1-5), your customer's information is saved in the system and you can step away from the process and resume by selecting "**Incomplete User**" (Refer to **4.1.3 Resume an Incomplete Registration**).

Step 2: Configure the Energy Communication Unit (ECU)

4. Click "**Add ECU**"

The Add ECU window is displayed.

4. Workspace (Installer Level)

5. Enter the 12-digit ECU UID number(s) into the ECU ID field.

The ECU UID is located on the back of the ECU, as well as on the front flap of the shipping box.



The ECU UID is a unique APsystems “serial number” that is assigned to the ECU during manufacturing. It is **NOT** the IP Address of the device.

It is critical that you enter the ECU UID correctly because the EMA uses this number to identify the system to ensure monitoring and reporting.

6. Click “OK”.

Once you have entered all of the ECU UID numbers to be installed at a specific location, go to step 3.

4. Workspace (Installer Level)

Step 3: Configuring the Inverter Information



Note

In order to improve the registration efficiency, you can skip this step and register inverters by scanning UID's in step 4 "Configure the Group View" directly.

7. Click **"Add Inverter"**

The Inverter Information page is displayed.

In this step you are assigning the inverters to their associated ECU(s).

8. Select the ECU (ECU Selection field).
9. Select the **"Add method"**.

There are three methods for adding inverters into EMA.

4.Workspace (*Installer Level*)

Note

Each inverter has a unique 12 digits UID which is located on the front of the inverter, as well as on the back flap of the inverter's shipping box.



4. Workspace (*Installer Level*)

➤ Add Method 1: Import from ECU (Recommend)

- A. Select “*Import from ECU*” in [Add Method]
- B. Click “OK”

20:16 [status icons]

< Add UID

INVERTER INFO ^

Collect the Inverter of PV system. UID is a 12-digit number located on the top of inverter, as well as on the front flap of the shipping box.

ECU ID *
216000056231

Add method *
Step1: Link ECU and inverter through "ID Management" by ECU APP at the installation site.
Step2: Connect ECU to the internet, report the link information to EMA.
Step3: EMA or EMA Manager read the link information and add the inverter ID automatically.
Import From ECU

OK

This method can only be used when the ECU has been already commissioned on site (using the ECU_APP) and connected to the internet. (please see ECU Quick Install Guide for more info)



Note




This list can be edited if necessary by selecting either “*Edit*” for each inverter and its associated channel.


4. Workspace (*Installer Level*)

➤ **Add Method 2: Input**

- Select "Input" in [Add Method]
- Select "Type".

20:15

   100%

 Add UID

INVERTER INFO ^

Collect the Inverter of PV system. UID is a 12-digit number located on the top of inverter, as well as on the front flap of the shipping box.

ECU ID *

216000056231

▼

Add method *

Add Inverter id through inputting the 12-digits number manually.

Input

▼

Type *

QS1

▼

Channel *

1,2,3,4

▼

UID *

12-digit number located on the top of inverter, or on the front flap of the shipping box.

OK

Note

You'll be presented with a number of inverter types. Select the type you are installing, remembering that the QS1, QS1A and YC1000 has up to four (4) channels (1, 2, 3 & 4), the YC600 has two (2) channels (1&2).

- C. Input the UIDs in the input box.

Note

Only UIDs matching the selected type can be added. If you select micro type “YC600” but enter UID of a QS1 “80x-”, an error message will be displayed.

- D. Click “OK”

4. Workspace (Installer Level)

➤ **Add Method 3: Scan**

A. Select “Scan” in [Add Method]

B. Select “Type”

20:16 100%
Add UID

INVERTER INFO ^

Collect the Inverter of PV system. UID is a 12-digit number located on the top of inverter, as well as on the front flap of the shipping box.

ECU ID *
216000056231

Add method *
Add inverter id through scanning the 12-digits barcode.
Scan

Type *
YC600

Channel *
1,2

Next




Note

You'll be presented with a number of inverter types. Select the type you are installing, remembering that the QS1, QS1A and YC1000 has up to four (4) channels (1, 2, 3 & 4), the YC600 has two (2) channels (1&2).

C. Click “Next”

The scanning page is displayed.

4. Workspace (Installer Level)



D. Scan the UID bar code.

Note

Only UIDs with the same type selected before can be scanned.

E. Click “OK”

Step 4: Configuring the Group View

This step will allow you to create the layout of the PV system.

11. Click “**Add Group View**”

The Create View page is displayed.

4. Workspace (Installer Level)

The image displays two side-by-side screenshots of the EMA Manager installer interface.

Left Screenshot (Add User):

- Personal Information:** Username : testuser, Address : China Zhejiang Jiaying
- ECU Information:** ECU : 216000056231, Timezone: Asia/Shanghai
- Inverter Information:** ECU : 216000056231, Number of Inverters : 2, 801000001234, 801000001235
- Group View Information:** (Empty field with a plus icon and 'Group View' label)

Right Screenshot (Create View):


- Group View Info:** Please register the module in accurate position according to the installation on the job.
- ECU ID:** 216000056231
- Group View Name:** 1-30 bit letters,digits,underscores,@,spaces,- or, please enter
- Row:** 1-80, please enter
- Column:** 1-80, please enter
- Next:** A button to proceed to the next step.

In this step you will fill in the basic view information.

12. Click “Next”

The panel layout page is displayed.


4. Workspace (*Installer Level*)




There are 2 modes to display the layout details: Module mode or list mode.

- **Module Mode:** Show the module position details in one page
- **List Mode:** Show the inverter UIDs with the position in a list format

4. Workspace (Installer Level)



There are 6 shortcut buttons to help you simplify the view registration.




- **Search:** Search UID.
- **Clear UID:** Delete UID located on the selected module.
- **Clear all UIDs in current row:** Delete all the UIDs located in the selected row
- **Clear all UIDs in current column:** Delete all the UIDs located in the selected column
- **Add row:** Add a new row of empty modules to the bottom of the view.
- **Add Column:** Add a new column of empty modules to the far right of the view.

4. Workspace (Installer Level)

There are 3 methods for adding views into EMA.

➤ Method 1: Distribute (Recommend)



A. Select the UID for the position

Note

When distribute the UIDs with the position, make sure you have registered the UIDs in step 3 (configuring the inverters information, see page 24), or you have entered all of the UIDs into the ECU, and that ECU is correctly connected to the internet so that the APsystems server can retrieve the UIDs.


B. Click “OK”

4. Workspace (Installer Level)

➤ Method 2: Input

A. Click  “Add Button” and choose “Input”

The input page is displayed.



Input the UIDs in input field, the channel will be auto filled after you entered the UID.

B. Click “Complete Input” after finishing inputting

4. Workspace (*Installer Level*)

14:03 P P

< Add view information

Collect the view of PV system. In order to manage and maintenance the PV systems, please register the modules in accurate position according to the installations on th job.

Grid of 10 module slots (2 rows, 5 columns). The 6th slot (row 2, column 5) is highlighted in orange.

Selected Module

R:2 C:5 Not Configured +

OK


C. Click “Ok”

4. Workspace (Installer Level)

➤ Method 3: Scan


A. Click **+** “Add Button” and choose “Scan”

The scan page is displayed.



Scan the UID bar code to collect the UIDs. Please register the modules in accurate position according to the installations on the job.

4. Workspace (Installer Level)



Note

Turn on “Auto Next”, the next empty panel will be automatically selected in horizontal sequence when scanning. Or else you need to choose the next panel.

- B. Click “Finish Scanning”
- C. Click “OK”

Note

The inverter ID can be registered as well even if it hasn't been registered in Step 3 “Configuring the inverter information” (see page 24)

4. Workspace (*Installer Level*)

20:21 2G 3G 4G 5G 100%

< Add User Delete

Personal Information

Username : testuser
Address : China Zhejiang Jiaxing

ECU Information

ECU : 216000056231
Timezone: Asia/Shanghai

+ ECU

Inverter Information

ECU : 216000056231
Number of Inverters : 2
801000001234 801000001235

+ Inverter

Group View Information

Group View : East View
R:2 C:2 Number of Panels: 4

+ Group View

13. Click “**Complete Registration**”


If your customer does not have installation drawings or photo to upload, the registration is complete.

Step 5: Uploading the System Picture and/or Drawing Picture (optional)

14. Click “**Upload Picture**”

The upload picture page is displayed.

4. Workspace (Installer Level)



The System Picture is displayed on the customer's Dashboard and the installation drawings are displayed on the customer's Module Performance page.


Following formats are supported:

- .jpeg
- .jpg
- .png
- .pdf

15. Click "Add"

Choose the installation drawing or photo you want to upload. Make sure you have authorized the EMA Manager APP to access to the pictures stored in your smart phone or tablet.

4. Workspace (Installer Level)



16. Once the pictures or drawings have been uploaded, Click “Back” and then “**Complete Registration**”.

4.1.2 Adding a New Share User Installation

Multiple customers’ PV system can be monitored via a single ECU using ECU Share mode. The “master” of ECU Share can see all sub-systems, while every owner of a sub-system can only see its own.

Require: First: register “Share ECU Master User”, then: register “Share ECU Sub User”.

➤ Master User

Manage all of the micros connected to the same ECU


➤ Sub User

Monitor their own system only

Note

In order to register sub-user via ECU Share mode, you need to have the “ECU Share” function enabled on your installer account. Please contact your local APsystems Technical Support to have this feature activated.

4. Workspace (Installer Level)



1. Select the “**Add Share User**” icon.

Start to add a new share user account.

4. Workspace (Installer Level)

Adding Share ECU Master User

The screenshot shows a mobile app interface for adding a 'Share User'. At the top, there's a yellow header with a back arrow, the title 'Share User', and status icons. Below the header, there are two tabs: 'Master User' (selected) and 'Sub User'. The form consists of five main sections, each with a header and a plus icon in a circle below it:

- Personal Information:** Header with a person icon, plus icon below.
- ECU Information:** Header with a car icon, plus icon below.
- Inverter Information:** Header with a battery icon, plus icon below.
- Group View Information:** Header with a group icon, plus icon below.
- Upload Picture(Optional):** Header with a picture icon, plus icon below.

There are five (5) major steps involved in adding a new Share ECU Master User (registering) in the EMA Manager. They are the same as the ones used to add a new user (For details, please refer to “*Adding a New User Installation*”).

Step 1: Personal Information - Entering the customer’s personal information.

Step 2: ECU Information - Configuring the Energy Communication Unit (ECU).


Step 3: Inverter Information - Configuring the Inverter Information.

Step 4: Group View Information - Configuring the Group View.

Step 5: Upload Pictures (optional) - System Picture and/or Drawing Picture

4. Workspace (Installer Level)

Adding Share ECU Sub User



There are four (4) major steps involved in adding a new Share ECU Sub User in the EMA Manager.

Step 1: ECU Information - Configuring the Energy Communication Unit (ECU).

Note

When add new share ECU sub user, you need to add the share ECU first.

Step 2: Personal Information - Entering the customer's personal information.

Step 3: Group View Information - Configuring the Group View.

Note


In this step, you are only permitted to arrange the inverters.

Step 4: Upload Pictures (optional) - System Picture and/or Drawing Picture.

4. Workspace (*Installer Level*)

4.1.3 Resume an Incomplete Registration


In case you were interrupted in any of the registration steps (1-5), your customer's information is saved in the system. You can resume the registration by selecting "*Incomplete User*" under "*User Management*".



1. Select the "*Incomplete User*" icon.

A list of your incomplete user registrations is displayed.

4. Workspace (*Installer Level*)



2. Select the customer account you want to complete.
3. Continue where you left off following the steps in the previous section. Refer to **[4.1 Adding a New User Installation]** or **[4.1.2 Adding a New Share User Installation]**.


4. Workspace (*Installer Level*)

4.2 Installer Management (*Installer Level*)

4.2.1 Adding a New Module

You can manage your module template or for your sub-installers.


The module template could be used to distinguish the module type installed at end-user.



1. Select the “**Module**” icon.

A list of module templates is displayed.

4. Workspace (Installer Level)



2. Click “Add” at the bottom right of the list.

The New Module page is displayed. Fill in the module details by field, make sure to include all required information.

Note

You can select a module to modify its information.

➤ Module Information

Installer Account Select the installer you want to add a new module template. It is displayed when you have a Master Installer account and sub-installers in your portfolio.

Panel Name This is a single “name” that identifies this specific panel (**Required**) Only “letters”, “numeric digits”, “underscores”, “@”, “spaces”, and “.” Can be used when creating a username. the username is not case sensitive. (**Required**)

4. Workspace (*Installer Level*)

<i>Module Maximum Power</i>	The maximum power of module template. (Required)
<i>Type</i>	The type of module template. (Required)
<i>Manufacturer</i>	Company name of module template. (Optional)
<i>Model</i>	The model of module template. (Optional)

4.3 Remote Control– ECU Management (*Installer Level*)


The ECU has been designed with remote connection and management functionality.

You can access this remote functionality through the EMA Manager APP, using your installer login credentials. Changes made remotely do not take effect until the ECU's next reporting cycle.

The ECU remote functionality allows you to do the following:


- Manage Inverter UIDs

4. Workspace (Installer Level)



1. Select the “**ECU-remote**” icon.


4. Workspace (*Installer Level*)



2. Enter the ECU ID

The remote control page is displayed. You can get overview the ECU's configurations, including the version of software in ECU, the time zone ECU set, the ECU's heartbeat (The last time ECU connected to the EMA) server.

4. Workspace (Installer Level)



Note


You can enter this function as well by clicking "**ECU-remote**" below "**Remote Control**".
Refer to **[3.4 Workspace (End User Level)]** - see pages 15.

4.3.1 Manage Inverter UIDs

1. Click the "**UID Manage**".

The "UID manage" page is displayed.

4. Workspace (Installer Level)



Note


If there are some micros UIDs registered in EMA but not sent to ECU, it will show a warning icon.

- **Synchronize** (Send the UIDs to ECU, then ECU will connect these inverters.)
You can send a list of UIDs registered in the EMA but not synchronized into the ECU, either one by one or as a group.
- **Clean** (Send the UIDs to ECU, then ECU will disconnect this inverters)
Select the UIDs you want to disconnect.

4. Workspace (*Installer Level*)

4.4 Company Management (*Installer Level*)

4.4.1 Adding a New Staff Account




1. Select the “**Staff Management**” icon.

A list of staff templates is displayed.

Note

If no staff is registered, the list will be empty. To add a new staff account, you will be forced to add department first. Refer to **[4.4.2 Add a New Department (*Installer Level*)]**

4. Workspace (Installer Level)



2. Click “Add” at the bottom right of the list.

The New Staff page is displayed. Fill in the staff details by field, make sure to include all required information.

➤ Staff Info

Username

This is a single “name” (typically the staff’s last name). The username appears in the customer’s area on the EMA. **(Required)**
Only “letters”, “numeric digits”, “underscores”, “@”, “spaces”, and “.” Can be used when creating a username. And the username is not case sensitive.

Password

This is a temporary password that is emailed to your staff so they can access their account on the EMA. Your staff can change their password should they so choose. **(Required)**
The set password must contain letters and numbers.

First Name

Your staff’s first name. **(Required)**

Last Name

Your staff’s last name. **(Optional)**

4. Workspace (*Installer Level*)

<i>Email</i>	This is your staff's email address. (Required)
<i>Phone</i>	Your staff's phone number. (Optional)
<i>Department</i>	Your staff's department. (Required)
<i>Staff ID</i>	Your staff's staff ID. (Optional)
<i>Position</i>	Your staff's position. (Optional)
<i>Entry Date</i>	Your staff's entry date. (Optional)
<i>Status</i>	Your staff's status. (Required)



Note

Staff cannot login EMA once you disable the account.

<i>Remarks</i>	Add any notes that you may find useful at a later date. (Optional)
----------------	--




Note

Once you finished registering a staff account and you can limit his manage areas and his roles.

4. Workspace (*Installer Level*)

4.4.2 Adding a New Department (*Installer Level*)




1. Select the “**Department Management**” icon.

A list of department templates is displayed.

Note

If no department is registered, the list will be empty.

4. Workspace (Installer Level)




2. Click "Add" at the bottom right of the list.

The New Department page is displayed. Fill in the department details by field, make sure to include all required information.

5. Local Control (*ECU APP*)

The ECU has been designed with local connection and management functionality. You can access this local functionality through EMA Manager.

Click "**ECU APP**" to enter this function.




You will be noticed if your smart phone or tablet do not connect to the ECU Wi-Fi at first.

- Step1: press the AP button of the ECU to activate the ECU wifi hot-spot



5. Local Control (*ECU APP*)

- Step2: Open Wi-Fi setting in your smartphone, select ECU's hotspot. Hotspot's name is similar to ECU's ID.



- Step3: Connecting to the ECU-R via the Local Wireless.

Note

The default password is “88888888”. (8 times 8)


- Step 4: Open EMA Manager.
- Step 5: Click “*ECU APP*” to enter “*Local Control*”

Note

Once logged-in, you can also click “*ECU APP*” at the upper right corner of “*Workspace*” to enter “*Local Control*”. **View it in “4. Workspace (Installer Level)”.**

5. Local Control (*ECU APP*)

5.1 Home (*ECU APP*)



On the home page, installer can visualize:

- Systems info of ECU ID
- The number of connected inverters communicating with the ECU / total number of inverters installed
- Today's power output
- Total power output since installation
- CO₂ Reduction since installation

The light in front of the ECU UID shows the status between mobile phone and ECU:


- ● : The mobile phone connects to the ECU.
- ● : The mobile phone fails to connect to the ECU.

The light in front of "Internet disconnected" shows the status between ECU and internet.

- ● : The ECU connects to internet.
- ● : The ECU fails to connect to the internet.

5. Local Control (ECU APP)

5.2 Module (ECU APP)



On the module page, installer can visualize the performance of inverters connected to the ECU.

According to different models of inverter, each inverter would have the corresponding panels displaying the real time power.

(even if some DC channels are not connected on purpose, the ECU_APP will display the maximum number of panels which can be connected to a given micro-inverter)


Example: if only 3 inputs of a QS1 or YC1000 are used, the ECU_APP will display 4 modules connected to the micro, even if the 4th module does not exist)

Removing the non-connected panel is done when creating the layout of the PV system in end-user account creation (step 4)

Click "Panel", the detailed information of the inverter shall be displayed, including inverter ID, PV module power, grid voltage, frequency and temperature.

5. Local Control (ECU APP)


5.3 Data (ECU APP)



In this page, you can view the detailed data on ECU level:

- Per day
- Per month

5. Local Control (ECU APP)




Note

If it is a ECU-C, with metering functions activated and CTs (current transformers) in place, you can also visualize PV production, house-hold consumption and grid import/export data on meter level.

5. Local Control (*ECU APP*)

5.4 Workspace (*ECU APP*)

In this View, you can manage the ECU's system information.




5. Local Control (ECU APP)

5.4.1 ID Management

➤ Add UID

Click “**Workspace**”, select “**ID Management**”, input the UID manually or scan the UID by camera. If there is no need to modify, then click “**Sync**” to update the UIDs onto ECU.



5. Local Control (*ECU APP*)

➤ Historical ID

You can find the UID used in history and you can restore them.

Select the desired history ID and click “Restore”, these IDs will be added in the ID list.

When you want to enter the inverter ID list in one ECU into another, this feature becomes very handy.



➤ Delete UID

Select the UIDs, click “Delete” then click “Sync”. The UIDs selected are deleted on the ECU.

5. Local Control (ECU APP)

5.4.2 Grid Profile

User needs to select grid profile when installing the system.

Grid Profile

Grid settings

Continent: Please Select >

Country: Please Select >

Grid profile: Please Select >

Please select the correct grid standard to ensure the safe operation of the system

Current grid profile

Cancel OK

Common

Asia	China	NB/T 32004:2018
Europe	Sri Lanka	Taiwan VPC
North America		Taiwan VPC(TB)
South America		

Grid Profile

Grid settings

Continent: Asia >

Country: China >

Grid profile: NB/T 32004:2018 >

Please select the correct grid standard to ensure the safe operation of the system

Current grid profile

Under voltage (stage 2) 60-219V	115.0 V
Under voltage 2 trip time 0.02-610s	0.02 s
Over voltage (stage 2) 221-276V	268.0 V
Over voltage 2 trip time 0.02-610s	0.02 s
Under voltage (stage 3) 60-219V	196.0 V
Under voltage 3 trip time 0.02-610s	0.05 s
Over voltage (stage 3)	253.0 V

Reset Update


Note

If you select a grid profile not adequate in your region, the inverters may not start or may not produce as per optimal performance

5.Local Control (ECU APP)

5.4.3 Inverter Connection Progress

Show the direct communication quality between each inverter and ECU. Show the connection progress and communication quality between each inverter and ECU, 100% means the connection is finished.



5. Local Control (ECU APP)

5.4.4 ECU Network Settings


➤ WLAN

The page will show up ECU's wireless connection status. Swipe down the screen and choose the available SSID to connect.

- Step1: Click the SSID.
- Step2: Enter the password.
- Step3: Click **"Send"**
- Step4: ECU restarts automatically.

Note

You need to reconnect your smart phone or tablet to the ECU's hotspot if the connections failed once the signals disappeared during the ECU restarting time.



➤ LAN

ECU's wired network setting has 2 options: automatically obtain an IP address or use a fixed IP address. Obtaining an IP address automatically means the router would distribute IP to ECU automatically. When use fixed IP, please enter IP address, Subnet mask, Default gateway, Preferred DNS server and Alternate DNS server.

The image displays two side-by-side screenshots of the LAN configuration interface in the EMA Manager application. Both screens show the same settings, but the toggle for 'Obtain an IP address automatically' is turned off in the left screenshot and turned on in the right screenshot.

Left Screenshot (Automatic IP disabled):

- Obtain an IP address automatically: ☐
- MAC address: 80:97:1B:02:6A:F7
- IP address: 192.168.131.228
- Subnet mask: 255.255.255.0
- Default gateway: 192.168.131.0
- Preferred DNS server: 0.0.0.0
- Alternate DNS server: 0.0.0.0
- Update button

Right Screenshot (Automatic IP enabled):

- Obtain an IP address automatically: ☒
- MAC address: 80:97:1B:02:6A:F7
- IP address: 192.168.131.228
- The remaining fields (Subnet mask, Default gateway, Preferred DNS server, Alternate DNS server) and the Update button are present but visually faded out.

5. Local Control (*ECU APP*)

5.4.5 ECU AP Settings

Please reconnect the ECU's hotspot after setting the password. On the page, you can change Password.

If user forgets the password, hardware reset could be carried out. The initial password would be "88888888".

3:38 PM

ECU AP Settings

Old Password Input old password

New Password Input password

Confirm Input password again

Please reconnect the ECU's hotspot after setting the password


Save

5. Local Control (*ECU APP*)

5.4.6 ECU Data Settings

Enter the page, the time and time zone of ECU shall be displayed on the right side of the page. Click “Date”, “Time” or “Timezone” to modify.


Click “Time quick setting”, APP will set the date and time of the phone for ECU, user doesn't need to set date and time manually.



5. Local Control (ECU APP)

5.4.7 Meter Settings

If it is a ECU-C, with metering functions activated and CTs (current transformers) in place, the meter settings will be displayed, and different control functions can be selected.



➤ Zero Export (only works with ECU-C in single phase and tri-phase systems)

Zero Export Function

- Only works with ECU-C in Single-phase and Three-phase systems
- Not compatible with Split-phase systems as commonly used in North American residential electrical service


Using the Zero Export function

- Select 'Meter Settings'
- Slide the 'Meter Function' to the 'On' position

5. Local Control (*ECU APP*)

- Select 'Zero Export' in the slide menu at the bottom of the page and select OK
- After turning on the Zero Export Function, please set a Power Limit in kW. The default value is 0.

The ECU-C measures the array production and site consumption and will curtail power production to meet (or exceed if selected) the site consumption. Example: if the Power Limit is set to 0 and the site is using 10kW and the array is producing 8kW the inverters will operate at 100%. Conversely, if the if the if the Power Limit is set to 0 and the site is using 3kW and the array can produce 8kW the inverters will curtail power production to meet the demand. In addition, the ECU-C is designed to dynamically adjust to the changing demand of the site automatically in real-time to realize the full potential of the array.



5. Local Control (*ECU APP*)

➤ Redundant Energy Control – only works with one single phase equipment


Redundant Energy Control Feature

- Only works with ECU-C in Single-phase
- Cannot be combined with zero-export feature

Using the Redundant Energy Control function

- Select 'Meter Settings'
- Slide the 'Meter Function' to the 'On' position
- Select the 'Redundant Energy Control' under 'Parameter settings'

This function is to control the opening of the external AC contactor by closing the ECU-C relay when the power of the uploaded power grid reaches a certain power value, to supply power to external electrical equipment e.g., water heater, pool pump, air conditioner, etc. Example: the power requirements of a water heater is 2kW, and the turn-on threshold can be set to 2.1kW (it is recommended to keep a margin), so when the array power exceeds 2.1KW compared to the house-hold consumption, the water heater is powered by the relay control and does not consume grid power.



5. Local Control (*ECU APP*)

➤ Three-phase Balance (only works with ECU-C in tri-phase systems)


Three-phase Balance Function

- Only works with ECU-C in Three-phase systems
- The balance is set to ensure that phase difference does not exceed 16 amps

Using the Three-phase Balance function

- Select 'Meter Settings'
- Slide the 'Meter Function' to the 'On' position
- Select the 'Three Phase Balance' under 'Parameter settings'

If a three-phase system comprised of APsystems' Single-phase micro-inverters e.g., YC600 or QS1, the user will have to manually configure which inverters serial numbers are connected to each separate phase in the 'Inverter 3-Phase Configuration' section and then select Save. There are two different methods for Phase loss detection; through an external CT for the fastest and most accurate response time and through the micro-inverter data collected every five minutes, a slower and less accurate method but does not require an external CT.




5. Local Control (ECU APP)

5.4.8 Automatic System Check


Check the running status of the system, if there are issues, click the icon to view the reason and check the installation to solve it

Please remember that the ECU_APP will always consider that all micro DC-inputs are connected to a PV panel (i.e: a quad is connected to 4 panels, a duo to 2 panels). As such, if one DC-input is not connected voluntarily, the ECU_APP will show a warning “channel no panel connected”. Based on knowledge of the system layout, the warning can be ignored



6. Do-It-Yourself Registration (ECU APP)

This only applies to home-owners “do it yourself” installers to create EMA account. Make sure the ECU has been configured properly using the steps described in section 5.1 to 5.4. Otherwise warning message is displayed, as shown below.



Make sure to connect your phone to the local internet and not to the ECU hot-spot. Then enter the information required (items with an * are mandatory) and click “Sync EMA”.

Then you will receive an email prompting you to open your EMA account. You can monitor the performance of your system using the EMA APP.

6. Do-It-Yourself Registration (ECU APP)

The screenshot displays the 'Personal Info' registration screen of the ECU APP. The form is organized into four main sections: ECU information, Account information, System information, and a final Sync EMA button.

ECU information

- ECU ID**: 216000075767
- UID**: 801000012354

Account information

- User name ***: 1~30 digits or letters
- Password ***: 6~75 digits or letters
- Full name ***: Please input
- Email ***: Please input
- Phone**: Please input


System information

- Country ***: Please select
- State ***: Please select
- City ***: Please input
- Address**: Please input
- Module Maximum Power(Pmax) ***: 200~1000W W
- Grid type ***: Please select

Sync EMA

7. Manage Your Information (*Installer Level*)

1. Once logged-in, Select the tab menu [**Settings**] at the bottom of the page.




In this function, you can manage your own registration information, view the introduction of the APP and get some helps.

7. Manage Your Information (*Installer Level*)

7.1 Modify Account Information (*Installer Level*)

1. Select the “**Edit**” at the upper right corner.

Edit the account details by field, make sure including all required information.



The screenshot shows a mobile application interface for editing account information. The title bar is orange with a back arrow and the text 'Account Information'. The status bar at the top shows the time 14:29, signal strength, Wi-Fi, and battery level at 57%. The form contains the following fields: 'Username *' with the value 'APSIInstallertest'; 'Firstname *' with the value 'APSIInstallertest'; 'Lastname -Optional' with the placeholder 'Please Input'; 'Email *' with the value 'emasupport@apsystems.cn'; 'Telephone -Optional' with the placeholder 'Please Input'; a toggle switch for 'Actively receive the alarming mail' which is currently turned off; and 'Remark -Optional' with the placeholder 'Please Input'. A character count '0/2048' is visible at the bottom right of the remark field. At the bottom of the form is an orange 'Submit' button.

2. Click “Submit”.

7. Manage Your Information (*Installer Level*)

7.2 Reset Password (*Installer Level*)

1. Select the “Reset password”.

Fill in the details by field.

14:40 P P

< Reset password

Previous Password *

Please Input

Password *

Length 6-32 bits, must contain numbers and letters.

Please Input

Confirm Password *

Length 6-32 bits, must contain numbers and letters.

Please Input

Submit

Note

Only when the previous password inputted is right, the new password can be set.


2. Click “Submit”.

7. Manage Your Information (*Installer Level*)

7.3 Modify Company Information (*Installer Level*)

1. Select the “Company Info”.

Edit the company details by field; make sure including all required information.



The screenshot shows a mobile application interface for editing company information. At the top, there is a status bar with the time 14:40 and various icons. Below it is a navigation bar with a back arrow and the title 'Company Info'. The main content area contains the APsystems logo and a list of form fields: 'Company Name' (required, with a red asterisk) containing 'APsystems'; 'Company Code' containing 'A20L7385'; 'Country' (required, with a red asterisk) set to 'China' with a dropdown arrow; 'State' (required, with a red asterisk) set to 'Zhejiang' with a dropdown arrow; 'City' (required, with a red asterisk) set to 'Jiaxing'; 'Address' (optional) with the placeholder 'Please Input'; 'Email' (required, with a red asterisk) containing 'emasupport@apsystems.cn'; 'Postal Code' (optional) with the placeholder 'Please Input'; and 'Telephone' (optional) with the placeholder 'Please Input'. At the bottom of the form is an orange 'Submit' button.


2. Click “Submit”.

7. Manage Your Information (*Installer Level*)

7.4 Change APP's Language (*Installer Level*)

1. Select the “Language”.

Select the language you need.



Note

APP supports 7 languages (English, 中文, 繁體中文, Español, Português, Français, Polski), so far, using the system language of the phone as its default language. If the system language is not included within these 7 languages, English is used as default.

2. Click “Submit”.